




## Setting up the Autocue wireless presenter

First go to the “QBox Status Panel”



Right-click your QBox (you probably only have one) and select “Device Settings”

Then select the tab that says “Configure Scroll Controls”




Click “Setup” after clicking the “Wireless Controller (Autocue Presenter)”.


A short explanation of the settings on the first page: the “Linear” box if left unchecked means that as you scroll the ball instead of incrementing equally (i.e. speed 1, 1.5, 2, 2.5, 3, 3.5, etc.) it goes much faster (1 times whatever the multiplier is, then times the multiplier again, and so on). You can experiment with this and see what works best for you. If you find the arrow “running away from you” you might want to try enabling linear mode.

Moving on... Click the second tab that says “Wireless Presenter (Autocue)”

You will see the screen below where you can configure the two always active button mappings no matter which mode it is in (more on that soon). One button is the trigger and the other is the “R” on top of the controller.



You will also see a drop-down if you click “Common” that will let you edit what the other buttons are mapped for both “Mode 1” and “Mode 2”.



If you would like to disable the blue info panel from displaying when the side-toggle switch is changed to either mode 1 or 2 (by sliding the switch up or down) then remap or change to “(Nothing)” all of the button on this mode.

For the sake of reference I am including below the default settings for Mode 1 below which would likely prove more helpful:

