

Components



| | |
|---|---------------------------------|
| A | Power Cable |
| B | On/Off Power Switch (1) |
| C | On/Off Power Switch (2) |
| D | Stand |
| E | Umbrella Hole |
| F | Lamp Holder x4 |
| G | Lamp Angle Adjustment |
| H | Stand Mounting Bolt |
| I | Mounting holes for softbox rods |
| J | Diffuser |
| K | Light Body |
| L | Hood with 4 rods |
| M | Lamp |

Softbox Lighting Kit

Our softbox lighting kit is designed to be used in video productions in which the lighting subject is likely to be a person(s).

This kit includes:

- Three 4-tube dimmable fluorescent softbox lighting heads
- Three aluminium lighting head stands
- A compact travel case

Specifications

| | |
|---------------------|-------------------------------|
| Heads | 3 |
| Tubes/head | 4 |
| Output (W) | 4 x 160 |
| Power (W) | 4 x 32 |
| Maximum Height (cm) | 190 to the centre of the head |
| Minimum Height (cm) | 91 to the centre of the head |
| Net weight (Kg) | 2.5 |

Softbox Lighting Kit Guide



Assembly



1. Insert the four hood rods in the mounting holes on the rim of the light head.

2. When the four rods are installed the hood will then be formed into a rectangular shape.



3. Ensure that the Velcro fastenings are secure.

4. Install all four lamps into the head.




5. When all the lamps are installed, to test the unit is working plug the unit in and switch the unit on using the power switches on the rear of the head.

6. Stretch the diffuser between all four corners of the hood.



7. Ensure that the diffuser is secured on all four sides using the Velcro strips.


8. The softbox is now complete and ready for use.



9. Mount the softbox on the top of the stand and secure in place using the clamp screw. (A)

Stand Adjustment

Open the legs by loosening the clamp screw and pull out to the desired angle and retighten the clamp screw. (A)



To adjust the height of the stand loosen the clamp screw and raise the stand to the desired height. (B)

